

# JJC Remote Handle Pistol Grip



JJC HR-DV handle pistol grip is a convenient handle for SONY camcorders with A/V R or LANC port and Blackmagic design pocket cinema camera. The pistol grip features finger grooves for ergonomic operation. The handle has a 1/4"-20 stud on its top surface, for sturdy attachment to the camcorder. There's a 1/4"-20 thread at the bottom of the handle, which allows you attach your mounted camcorder to a tripod or head. At the left side of the HR-DV has a ACC socket for a cable to connect the camcorder and this HR handle. The start/stop button allows you remotely control the video recording without touch the camcorder. The unique LOCK button will safely lock the start/stop button to prevent unwanted start/stop button pressing. Now you can enjoy a fluently video recording.

## Product Highlights

- Provides two cables fit SONY camcorders with A/V R or LANC port and BMPCC camera
- Cable stretchable to 0.5m
- Control video stop and start without shaking device
- Easily mounts to the bottom of camcorder
- Thumbwheel for Easy attachment
- Bottom has a 1/4"-20 hole for mounting on a tripod or head
- Unique safety LOCK design provides you fluently recording
- No battery required and easy to use

## Compatible with

<b>Blackmagic design</b>
Blackmagic design pocket cinema camera

<b>SONY High Definition on Hard Disk Drive (AVCHD)</b>			
HDR-XR160E	HDR-XR155E	HDR-SR10E	HDR-SR11E
HDR-SR12E	HDR-SR5E	HDR-SR7E	HDR-SR8E
HDR-SR1E			
<b>SONY High Definition on Hard Disk Drive (AVCHD)</b>			
HDR-TD10E	HDR-CX115	HDR-CX130E	HDR-CX360VE
HDR-PJ10E	HDR-PJ30VE	HDR-CX700VE	HDR-CX520VE
HDR-CX350VE	HDR-CX305E	HDR-CX155E	HDR-CX105E
HDR-CX11E	HDR-TG3E	HDR-CX6EK	
<b>SONY High Definition on disc (AVCHD)</b>			
HDR-UX19E	HDR-UX3E	HDR-UX7E	HDR-UX1E
<b>SONY High Definition on tape (HDV)</b>			
HDR-FX1000E	HDR-HC9E	HDR-HC5E	HDR-HC7E
HDR-HC3E			
<b>SONY Standard Definition on Hard Disk Drive</b>			
DCR-SR37E	DCR-SR57E	DCR-SR77E	DCR-SR35E
DCR-SR55E	DCR-SR75E	DCR-SR210E	DCR-SR32E
DCR-SR52E	DCR-SR72E	DCR-SR190E	DCR-SR290E
DCR-SR30E	DCR-SR50E	DCR-SR70E	DCR-SR90E
DCR-SR33E			
<b>SONY Standard Definition on Flash Memory</b>			
DCR-SX45E	DCR-SX30E	DCR-SX50E	
<b>SONY Standard Definition on Disc (DVD)</b>			
DCR-DVD150E	DCR-DVD450E	DCR-DVD110E	DCR-DVD310E
DCR-DVD410E	DCR-DVD106E	DCR-DVD109E	DCR-DVD306E
DCR-DVD406E	DCR-DVD506E	DCR-DVD105E	DCR-DVD202E
DCR-DVD203E	DCR-DVD205E	DCR-DVD304E	DCR-DVD403E
DCR-DVD404E	DCR-DVD405E	DCR-DVD505E	DCR-DVD7E
DCR-DVD92E			
<b>SONY Standard Definition on Tape (MiniDV)</b>			
DCR-HC51E	DCR-HC62E	DCR-HC27E	DCR-HC37E
DCR-HC45E	DCR-HC47E	DCR-HC18E	DCR-HC19E
DCR-HC20E	DCR-HC22E	DCR-HC24E	DCR-HC30E
DCR-HC32E	DCR-HC35E	DCR-HC39E	DCR-HC40E
DCR-HC42E	DCR-HC44E	DCR-HC46E	DCR-HC90E
DCR-HC94E	DCR-HC96E	DCR-PC1000E	DCR-PC53E
DCR-PC55E			
<b>SONY MICROMV</b>			
DCR-IP1E	DCR-IP5E	DCR-IP7E	
<b>SONY HD DV tape portable recorder</b>			
GV-HD700E			

<b>SONY High Definition on Hard Disk Drive (AVCHD)</b>			
HDR-SR5E	HDR-SR7E	HDR-SR8E	HDR-SR1E
High Definition on disc (AVCHD)			
HDR-UX3E	HDR-UX7E	HDR-UX1E	
High Definition on tape (HDV)			
HDR-FX1000E	HDR-HC9E	HDR-HC5E	HDR-HC7E
HDR-FX1	HDR-HC1E	HDR-HC3E	
<b>SONY Standard Definition on Hard Disk Drive</b>			
DCR-SR52E	DCR-SR72E	DCR-SR190E	DCR-SR290E
DCR-SR50E	DCR-SR70E	DCR-SR90E	
<b>SONY Standard Definition on Disc (DVD)</b>			
DCR-DVD306E	DCR-DVD406E	DCR-DVD506E	DCR-DVD100E
DCR-DVD101E	DCR-DVD200E	DCR-DVD201E	DCR-DVD202E
DCR-DVD203E	DCR-DVD304E	DCR-DVD403E	DCR-DVD404E
DCR-DVD405E	DCR-DVD505E	DCR-DVD91E	DCR-DVD92E
DCR-TRV80E			
<b>SONY Standard Definition on Tape (MiniDV)</b>			
DCR-HC14E	DCR-HC18E	DCR-HC19E	DCR-HC20E
DCR-HC22E	DCR-HC30E	DCR-HC32E	DCR-HC39E
DCR-HC40E	DCR-HC42E	DCR-HC85E	DCR-90E
DCR-HC94E	DCR-HC96E	DCR-HC1000E	DCR-PC1000E
DCR-PC101E	DCR-PC103E	DCR-PC105E	DCR-PC106E
DCR-PC107E	DCR-PC109E	DCR-PC120E	DCR-PC330E
DCR-PC350E	DCR-TRV22E	DCR-TRV50E	DCR-VX2000E
DCR-VX2100E			
<b>SONY Digital 8</b>			
DCR-TRV25E	DCR-TRV33E	DCR-TRV340E	DCR-TRV355E
DCR-TRV60E	DCR-TRV740E		
<b>SONY Hi 8</b>			
DCR-TRV14E	DCR-TRV19E		
<b>SONY MICROMV</b>			
DCR-IP220E	DCR-IP55E		
<b>SONY Other series</b>			
DSC-R1	DSC-F828	DSC-F717	DSC-F707
DSC-V1	DSC-V3		

and other SONY camcorders with A/V R or LANC port.

[WWW.JJC.CC](http://WWW.JJC.CC)