



KIWIFOTOS UR-232 Tasman Camera Remote Switch has 15 models to be compatible with CANON, NIKON, OLYMPUS, SONY, PANASONIC, PENTAX, SIGMA, MINOLTA, SAMSUNG, FUJIFILM etc. cameras. You can easily use this remote switch on different cameras by changing the connecting cables. This remote switch is designed to reduce camera shake to an absolute minimum. It is a perfect choice for taking long exposure photos. The remote has a two-stage release button, half-press to focus, fully press to trigger the shutter and take a photo. For long exposure, please press the release button fully and slide it into the locked position. The shutter will stay open as long as the shutter release button is locked. To unlock the shutter, just slide the release button back to its original position. This remote is powered by camera, you don't need to install a battery.

Specification

Size (L x W x D): 90.00mm x 29.82mm x 17.40mm

Weight: 23.20g

Material: Plastic

Battery type: No Battery Required

Connecting cord length: 0.7m + 1.3m(extended cord)

Features

- Halfway pressing for auto focus
- Complete pressing for picture taken
- Lock the button for long exposures or continuous shooting
- Prevent the camera from shaking
- Cable interchangeable to fit different cameras
- Powered by camera

Compatibility

UR-232A replaces CANON RS-80N3

UR-232B replaces NIKON MC-30 / MC-36 / MC-36A

UR-232C replaces CANON RS-60E3 / PENTAX CS-205

UR-232D replaces PANASONIC DMW-RSL1

UR-232E replaces OLYMPUS RM-CB1

UR-232F replaces MINOLTA RC-1000S/L / RM-S1AM / RM-S1LM

UR-232G replaces NIKON MC-DC1

UR-232M replaces NIKON MC-DC2

UR-232J replaces OLYMPUS RM-UC1

UR-232H replaces SIGMA CR-11

UR-232I replaces SIGMA CR-21

UR-232K replaces FUJIFILM RR-80

UR-232N replaces SAMSUNG ED-SR2NX02

UR-232O fits FUJIFILM FINEPIX HS50EXR

UR-232R replaces FUJIFILM RR-90